PR100B User Manual
(For Tablet Placement)

Step 1, Opening the Stand:

Separate the top and bottom panels first, then unfold the middle piece and place it flat on the table.

①   ②Separate with force   ③Lift up with force   ④

Step 2, Connecting the Tablet to the Dock:

Place the tablet onto the stand. Connect the dock's HOST port using the included USB-C to USB-C cable to the tablet's USB-C port (The USB-C port must be a full-feature port or USB3.0 or higher).

(After connection, all ports of the dock can start working normally. Note: Only one of the TF/SD card slots can work at a time; the one inserted first will be active.)

Step 3, Powering the Tablet:

Use a PD (45W or above) charger to connect to the dock's PD port for power supply.